



*When designing and building sanitation works, attention should be paid to ease of access to those areas where components are to be sited and their degree of vulnerability*



Source: Grases, José



Source: Acquaviva / 2000



*When rehabilitation is carried out without applying prevention criteria, the components may remain as vulnerable as they were before the disaster*



Source: OPS / OMS

◀ Incorporation of mitigation measures

Source: OPS / OMS



Vulnerability revisited ▶





*In emergency situations, plans for alternative water distribution need to be in effect*



Source: OPS / OMS

Source: OPS / OMS

